



Guardian /Guardian II Lift Interlock (GRD601/602-A) - Installation Instructions

Application

**Chevy Full Size Van (GMT 610) – 2001-2002
Auxiliary Kit # GRDC1**

Note: Only use this kit for the above application or damage to the vehicle may result!

This kit contains two adapters. Both are identical and can be used interchangeably. However, both must be used! Find the Chevy Guardian Vehicle Harness from the original kit. It will have a “T” consisting of two gray 6 pin connectors. Attach one of the adapters to the male connector. Attach the other adapter to the female connector. Ensure that both connections are fully seated. The vehicle harness can now be installed into the vehicle as per the normal procedure. See Below:

VEHICLE HARNESS -

2001-2002 models require Auxiliary Kit # GRDC1. Do not install the wrong application harness or damage to vehicle will result!

Gray 6-Pin Connector – Disconnect the gray, 6-pin Chevrolet connector located behind the left side of the lower dash panel directly behind the park brake release handle. Separate the Chevrolet connector and plug the Guardian 6-pin connector between the two ends of the Chevrolet connector.

Park Brake Connector – Disconnect the black, single-wire Chevrolet connector from the park brake switch. Plug the female side of the Black connector from the Guardian Vehicle harness to the parking brake. Install the male spade side to the female connector in the Chevrolet harness.

Finally, plug the 6 pin white connector into the Guardian Module in the connector labeled “Vehicle 1” and plug the 4 pin white connector into the connector labeled “Vehicle 2”.

Secure the Guardian Module in its final location and test for proper operation. (See Operating Instructions).
