



An ISO 9001:2000 Registered Company

BrakeMax BMC601-A Installation Instructions 2003-07 Chevy (GMT 610) Gas Engines Only!

Reference the appropriate vehicle shop manual as needed and use proper shop practices to protect personnel and vehicle.

HARNESSES

1. Disconnect the battery negative cable.
2. Locate the OEM GRAY, 6-pin connector above and forward of the park brake pedal. Separate the connector and connect the BMC601 GRAY, 6-pin connector in-series with the OEM connector halves. Ensure that the connectors are fully seated.
3. Pull the OEM TOW/HAUL switch forward to reveal the back of the switch.
4. Remove the OEM BLACK, 4-pin connector from the OEM TOW/HAUL switch and connect the BMC601 BLACK, 4-pin connector in-series with the OEM connector and the switch.
5. Position/secure the BMC601 Control Module under the dash near the steering column area.
6. Plug the BMC601 Harness Connector into the BMC601 Control Module.

FINAL STEPS AND INSPECTION PROCEDURE

7. Prior to replacing components, perform a functional test. Connect the battery negative cable.
8. Set the park brake and start the engine.
9. Verify that the "Tow/Haul" light illuminates on the vehicle display.
10. Finish routing of the BMC601 harness and retain as needed to protect the harness.



An ISO 9001:2000 Registered Company

BrakeMax Operation Instructions

- When the vehicle is started, tow-haul mode is automatically engaged and the tow-haul light will be on.
- To deactivate tow-haul mode, press the tow-haul mode button.
- When vehicle is restarted, tow-haul mode will again be automatically reengaged.
- See OEM owner's manual for features and benefits of tow-haul mode.